

To Starter Relay

Stator

Stator

Stator

Charging
Indicator
Lamp

“N”
under
front
cover

Voltage Regulator

Ground

